

## Fitting Instructions

### Side & Barn Door Blackout Curtains (NOT Tailgate)

#### Tools required:

Drill 2.5mm Bit  
Screwdriver PZ1  
Pen

1. Drill all curtain rail screw holes



2. Insert screws into curtain rail holes



3. Thread curtains sliders onto rails



4. Insert endcaps and secure by drilling holes and inserting screws



5. Mark point before drilling and screwing poppers by hand



**Please be aware that due to manufacturing screw colours and poppers may vary between curtains.**

**These curtains may be NOT suitable for Carvelle and Shuttle Vehicles due to the interior window surround plastics.**

**Please do also watch the tutorial YouTube Videos**

*N.B: Please note that whilst every attempt is made to ensure that these instructions are accurate and clear, we cannot be held responsible for the misinterpretation of these instructions or for any subsequent accident or damage caused through mis-fitted parts.*