



campervanparts.uk

THERMAL SCREENS

Instructions:

This product can be delicate. When preparing this product for use, please support the eyelet whilst inserting the suckers (this works best using a screwing motion).

To fasten screens, push the suckers onto the glass. If the suckers are not sticking well you may need to clean the glass (clean glass can sometimes have a film of dirt that will need to be cleaned for best results). Moistening the sucker can also help. The suckers can sometimes become misshapen which will cause the suckers not to stick. This can easily be rectified by putting the sucker cup in some warm water before sticking it the glass to help regain its shape.

To remove the screens, pull on the suckers one by one, **never removing them by pulling the material**. If the windows have a darkened tinting film on them then the suction may lift this film so extra care needs to be taken. The suckers can easy be removed by lifting the edge of the material and removing the sucker by gently touching the edge of the sucker cup to break the seal.

N.B: Please note that whilst every attempt is made to ensure that these instructions are accurate and clear, we cannot be held responsible for the misinterpretation of these instructions or for any subsequent accident or damage caused through mis-fitted parts.